




How to Launder the TASKI® Jonmaster system


1. Sorting the laundry



Divide soiled mops and cloths and place in separate nets.



Placing 10-15 mops in a net will give optimum wash results.



Placing 20 cloths in a net will give optimum wash results.




Ensure laundry net is securely fastened by tying cord around neck of the net and fastening button, take to the laundry.

Golden rules

1. Always replace the dirty mops with clean ones after each room.
2. Always start from the cleanest area before moving on to a more dirty area.
3. Remember – launder cloths and mops separately.
4. Never re-use the mops after they have been used in the washroom area.
5. Never use the mops on rough or concrete surfaces.


2. Washing procedures




Only load the washing machine to 3/4 full to ensure good mechanical action.



Do not mix loads of cloths and mops to obtain optimum wash results.



Select the correct wash programme/ temperature. Never wash at above 92°C as this may result in shrinkage of the laundry nets.



Diversey Laundry Detergent will be automatically dispensed into the wash via the dosing unit.




Never use fabric softeners when washing TASKI Jonmaster cloths and mops.


3. Loading the dryer




Keep wet net bags off the floor at all times by placing them in white clean laundry trolley.




Never overload the dryer as this may increase the drying time. Ensure filters are clean.




Select the correct drying programme/temperature for the TASKI Jonmaster mops and cloths. Never dry at above 60°C as this will damage the fibres.



Once load is dry, allow to cool and remove from the dryer.



Place nets containing clean mops/cloths into white clean laundry trolley.



At the end of the day, wipe the white laundry trolley clean using red TASKI Jonmaster cloth.

