



# Diversey VeriClean™ System

## Fluorescent Marking Spray & UV/Black Light

### Description

An innovative program to evaluate and enhance cleaning performance designed for healthcare.

### Features & Benefits

- The Diversey VeriClean System is a comprehensive cleaning validation solution that includes the use of a fluorescent marking spray along with a UV/black light to allow the user to spray a small quantity of liquid onto a surface that will leave an invisible marker when dry. After the surface is cleaned, the user can use the black light to detect whether the mark was removed, and thus whether the surface was properly cleaned.
- The marker can be applied to vertical, horizontal, or the underside of surfaces with ease.
- Marked surfaces are easy to detect.
- Sprayer applies a large circle (15cm diameter), giving better clarity to the quality of cleaning than a single spot.

### Application areas

- Healthcare
- Education
- Lodging





# Diversey VeriClean™ System

## Fluorescent Marking Spray & UV/Black Light

### Directions for use

1. Uncap the spray pen and hold it 15–23cm above the surface to be marked.
2. Apply a single spray of solution to the surface and allow surface to air dry.
3. After room cleaning, use black light to test if surface has been cleaned properly.
4. To use black light, hold it at a 45° angle to the surface, pointing away from the user. Never point black light at anyone's eyes.

Ideal on hard surfaces such as ceramic, tile, tub and walls.

Technical data			
Appearance	Clear yellow liquid	Odour	Alcohol
Flash point	50.1°C	Shelf life	1 year
Volatile Organic Compounds (VOC)	5% complete	Specific gravity	0.994

*The above data is typical of normal production and should not be taken as a specification.*

Product	Pack size	SKU Code	Availability
Diversey VeriClean System UV/Black Light (requires 3AAA batteries, not included)	4 x 1	95696916	ANZ
Fluorescent Marking Spray* <ul style="list-style-type: none"><li>• 0.05ml per spray</li><li>• 200 sprays per 10ml tube</li></ul>	6 x 10ml	95696861	ANZ

### Safe handling and storage information

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures.

### Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at [www.diversev.com](http://www.diversev.com) or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.

For additional information, please contact us at:  
Diversey Australia Pty Ltd Toll free: 1800 647 779, Diversey New Zealand Ltd Toll free: 0800 803 615 [www.diversev.com](http://www.diversev.com)  
Legal disclaimer: The associated products or services are manufactured by or otherwise emanate from Diversey Companies and their subsidiaries and not from Sealed Air.