

The Diversey VeriClean™ System

Marking High Touch Surfaces* with the Diversey VeriClean™ System Fluorescent Spray:

Hold the Diversey VeriClean System Fluorescent Marking Spray 15-23cm away from the surface to be marked. Press the pump once to dispense a small amount of liquid marker on the surface. Allow the surface to dry.

Using the **Patient Room Audit Form**, check "Removed" to capture the marked surfaces or Using the **iMAP Audit Tool**, select "Yes" to capture the marked surfaces.



Patient Care Surfaces:

Call button/remote control



Telephone



Bed rail & bed control panel



Patient over bed table



Bedside table



Patient / visitor chair



Restroom Surfaces:

Toilet flush handle



Toilet hand holds / rails



Patient pull cord



Wall area around toilet



Toilet seat, bowl and booster



Wall area around toilet



Restroom door handle



Sink and faucet handles



Portable commode



Restroom light switch



Room door handle/knob



Room light switch



*Note: Your facility may have additional surfaces to be tested

Room Entrance Surfaces: