

Diversey

## VeriClean™ System

### Fluorescent Marking Spray & UV/Black Light

**An innovative program to evaluate and enhance cleaning performance designed for healthcare.**

The VeriClean System is a comprehensive cleaning validation solution that includes the use of a fluorescent marking spray along with a UV/black light to allow the user to spray a small quantity of liquid onto a surface that will leave an invisible marker when dry. After the surface is cleaned, the user can use the black light to detect whether the mark was removed, and thus whether the surface was properly cleaned.

#### Easy-to-Use

- ▶ The marker can be applied to vertical, horizontal, or the underside of surfaces with ease
- ▶ Marked surfaces are easy to detect
- ▶ Sprayer applies a large circle (6" diameter), giving better clarity to the quality of cleaning than a single spot

#### Designed For

- ▶ Healthcare
- ▶ Education
- ▶ Lodging



### Directions for Use

1. Uncap the spray pen and hold it 15–23cm above the surface to be marked.
2. Apply a single spray of solution to the surface and allow surface to air dry.
3. After room cleaning, use black light to test if surface has been cleaned properly.
4. To use black light, hold it at a 45° angle to the surface, pointing away from the user.  
Never point black light at anyone's eyes.

### Technical Data Fluorescent Marking Spray

Description	
<b>Colour/Form</b>	Clear yellow liquid
<b>Flash Point</b>	50.1° C
<b>pH</b>	7.7
<b>Odour</b>	Alcohol
<b>Shelf Life</b>	1 year
<b>Volatile Organic Compounds (VOC)</b>	5% Complete
<b>Specific Gravity</b>	0.994

### Available Items

Code	Description	Availability
95696916	4 x 1 UV/Black Light (requires 3 AAA batteries, not included)	ANZ
95696861	6 x 10 ml Fluorescent Marking Spray*	ANZ

\* 0.05ml per spray  
\* 200 sprays per 10ml tube

These figures are typical values and should not be interpreted as specifications.

### Safe handling and storage information

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available on [www.sealedair.com](http://www.sealedair.com).

### Safety Reminder:

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at [www.sealedair.com](http://www.sealedair.com) or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.