



How to


Use TASKISUM Single Use Microfibre Mops




1 Attach the mop to the mop head by applying pressure downwards.




2 Adjust mop handle to comfortable height (chest level). Loosen handle by turning handle lock quarter of a turn to the left and pulling handle upwards. Lock handle in position by turning handle lock half a turn to the right.




3 Mop the floor with the leading edge of the mop starting at the furthest point from the exit, following a figure of 8 motion. For tough stains apply extra pressure to mop head using the ball of your foot.



4 When mop is soiled, remove from the mop head by stepping on the 2 edges of the mop. With both hands, pull the handle upwards to release the mop.



5 Place the mop head sideways across the mop and lift off the floor. Place in the refuse bag.



6 Replace the dirty mop with a clean one by repeating Step 1 above.

Golden Rules

1. Always dispose the soiled mops and replace them with clean ones after each room.
2. Always start from the cleanest area before moving on to a more dirty area.

