



# Divercleanse



## Hospital Grade Disinfectant

### Description

Divercleanse is a One Step Hospital Grade Disinfectant which kills germs, bleaches and removes stains, odour and soils from surfaces. Divercleanse can be used on shower recesses, tiles, toilets, washrooms, floors and other hard surfaces. Divercleanse is effective against micro-organisms including *Pseudomonas aeruginosa*, *Escherichia coli*, *Proteus vulgaris* and *Staphylococcus aureus*.

### Features

- Divercleanse is a Hospital Grade Disinfectant, AUST L 106816 and AUST L 280283.
- Eliminates mould and bacteria.
- Cleans, disinfects and deodorises in one product.
- Suitable for most washroom applications.
- Removes unpleasant smells.

### Benefits

- Highly versatile cleaner/ disinfectant which has been specially designed to cling to sloping or vertical surfaces, greatly enhancing the cleaning, deodorising and disinfecting properties.
- Especially suited for cleaning of washroom surfaces, drains and waste pipes, refuse receptacles and bins.
- Remove stains from items such as tea and coffee urns and dish cloths.

### Application areas

- Lodging
- Office Buildings
- Education
- Healthcare
- Retail



**AUST L 280283**



**AUST L 106816**



# Divercleanse



## Hospital Grade Disinfectant

### Directions for use

**Hospital Grade Disinfectant:** - Prepare 128ml per 750ml of solution (5,000ppm). Apply to surface and leave for 10 minutes.

**Infection Control Cleaning** - Apply diluted Divercleanse on to surface. Leave for 5 minutes. Scrub or wipe if required. Rinse well with water.

### Dilution:

- 10,000ppm – AU recommendation for cleaning of Blood Spills. Prepare 252ml per 750ml of solution.
- 5,000ppm – NZ recommendation for cleaning of Blood Spills. Prepare 128ml per 750ml of solution.
- 1,000ppm\* – recommendation for Environmental cleaning of surfaces contaminated with *C. difficile*. Prepare 27ml per 750ml of solution. Always disinfect after cleaning with a disinfectant registered for specific efficacy against *C. difficile*.
- 1,000ppm – recommendation for Environmental cleaning. Prepare 27ml per 750ml of solution.

**General Cleaning:** Use undiluted to remove mould, stains and odour, use on showers, toilets, drains, rubbish bins and chopping boards. Rinse well with water.

For use as a cleaner, dilute 125ml into 5L of water (1:40) to remove germs from washroom surfaces and floors, and to remove stains in tea and coffee cups. Rinse items / surfaces with water.

Store below 25°C. Not intended to be used on therapeutic devices. Do not mix with detergents or other chemicals. Discard diluted solution after use.

\*NHMRC, section B1.4.2 Routine environmental cleaning and HPS 2008, section 2.2.7 Environmental cleaning.

In New Zealand: MPI Approved C 32 (All animal product except dairy).



# Divercleanse

## Technical data

Appearance	Pale, yellow liquid	Specific gravity (20°C)	1.08
Odour	Slightly perfumed	pH (concentrate)	12.9
Active Ingredient	Sodium hypochlorite 4.6% w/w(Available Chlorine 4.4% w/w)	Dilution	Hospital Grade Disinfectant - Neat Infection Control cleaning - See Directions for Use Manual cleaning - 125ml to 5L water

*The above data is typical of normal production and should not be taken as a specification.*

Product	Pack size	SKU Code	Availability
Divercleanse	12 x 750ml	HH14333	AU & NZ
Divercleanse	2 x 5L	HH14336	AU & NZ

## Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet. Store in original container. Store below 25°C. Not intended to be used on medical devices. Do not mix with detergents or other chemicals. Discard diluted solutions after use.

## Product compatibility

Under recommended conditions of use, Divercleanse is highly versatile and is suitable on most washroom surfaces such as shower recesses, tiles and toilets, as well as drains and waste pipes, refuse receptacles and bins. Divercleanse can also to remove stains from items such as tea and coffee urns and dish cloths. Divercleanse contains chlorine. Always spot test and ensure surface suitability before use. May discolour fabrics and surfaces. Do not use on enamel, laminates or porcelain if cracked or worn.

## Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at [www.diversey.com](http://www.diversey.com) or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.

For additional information, please contact us at:  
Diversey Australia Pty Ltd Toll free: 1800 647 779, Diversey New Zealand Ltd Toll free: 0800 803 615 [www.diversey.com](http://www.diversey.com)

© 2018 Diversey, Inc. All Rights Reserved.