



# Diversol 5000



# D4.6z

## Hospital Grade Disinfectant

### Description

Diversol 5000 is a chlorinated Hospital Grade Disinfectant designed for disinfection of blood spills. Diversol 5000 is also a rinse free sanitiser designed for sanitising pre-cleaned hard non-porous surfaces such as benches and tables.

Diversol 5000 is effective against *Pseudomonas aeruginosa*, *Escherichia coli*, *Proteus vulgaris* and *Staphylococcus aureus*.

### Features

- Diversol 5000 is a hospital grade disinfectant specifically designed for use in blood spill kits.
- Diversol 5000 is conveniently packaged in a 25g sachet allowing for accurate preparation of either disinfecting or sanitising solutions when needed.
- Diversol 5000 is a Hospital Grade Disinfectant, AUST L 61650.

### Benefits

- Consistent chlorine content every time.
- Eliminates need for storage of large quantities of liquid.
- Eliminates wastage, prepare solutions as required.
- Easy preparation of 10,000ppm and 1,000ppm solutions required by Infection Control Guidelines.

### Application areas

- Lodging
- Office Buildings
- Education
- Healthcare
- Retail





# Diversol 5000



# D4.6z

## Hospital Grade Disinfectant

### Directions for use

**Disinfection of blood spills:** Add 1 sachet to 500mL of water to disinfect surfaces contaminated with blood, urine, faecal matter etc. Apply product to surface. Leave for 10 minutes. Remove and rinse.

**Sanitising:** Add 1 sachet to 10L of water for a general sanitising 500ppm solution.

**Sanitising no rinse:** Add 1 sachet to 50L of water for a rinse free 100ppm sanitising solution.

Ensure contents are fully dissolved. Discard diluted solutions after use. Not intended for use on therapeutic devices. Do not mix with detergents or other chemicals. Store below 30°C.

Technical data			
Appearance	White free-flowing powder (purple solution)	pH	9.0 (10,000ppm)
Odour	Chlorine	Shelf life	2 years
Active Ingredient	Sodium dichloroisocyanurate 40%w/w (Available chlorine 22%w/w)	Dilution	<b>Disinfection of blood spills</b> 1 sachet to 500ml water (10,000ppm) <b>Sanitising of blood spills</b> 1 sachet to 5L water (1,000ppm) <b>General surface sanitising</b> 1 sachet to 10L water (500ppm) 1 sachet to 50L water (100ppm rinse)

*The above data is typical of normal production and should not be taken as a specification.*

Product	Pack size	SKU Code	Availability
Diversol 5000	200 x 25g	HH11121	AU

### Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet. Store in original container. Do not mix with other detergents or chemicals. Store below 30°C.

### Product compatibility

Under recommended conditions of use, Diversol 5000 is suitable on hard non-porous surfaces such as benches and tables. Not intended for use on therapeutic devices.

### Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at [www.diversey.com](http://www.diversey.com) or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.