

Divercleanse

Hospital Grade Disinfectant

Divercleanse is a One Step Hospital Grade Disinfectant which kills germs, bleaches and removes stains, odour and soils from surfaces. Divercleanse can be used on shower recesses, tiles, toilets, washrooms, floors and other hard surfaces. Divercleanse is effective against microorganisms including *Pseudomonas aeruginosa*, *Escherichia coli*, *Proteus vulgaris* and *Staphylococcus aureus*.

Features:

- ▶ Divercleanse is a Hospital Grade Disinfectant, AUST L 106816 and AUST L 280283
- ▶ Eliminates mould and bacteria
- ▶ Cleans, disinfects and deodorises in one product
- ▶ Suitable for most washroom applications
- ▶ Removes unpleasant smells

Benefits:

- ▶ Highly versatile cleaner/ disinfectant which has been specially designed to cling to sloping or vertical surfaces, greatly enhancing the cleaning, deodorising and disinfecting properties
- ▶ Especially suited for cleaning of washroom surfaces, drains and waste pipes, refuse receptacles and bins
- ▶ Remove stains from items such as tea and coffee urns and dish cloths

Designed For

- ▶ Healthcare
- ▶ Lodging
- ▶ Office Buildings
- ▶ Education
- ▶ Retail



AUST L 106816

AUST L 280283

Directions for Use

Infection Control Disinfection as a Hospital Grade Disinfectant

Apply undiluted to surface and leave for 10 minutes.

Infection Control Cleaning

Apply diluted Divercleanse on to surface. Leave for 5 minutes. Scrub or wipe if required. Rinse well with water. Discard diluted solution after use.

Dilution:

- ▶ 10,000ppm – AU recommendation for cleaning of Blood Spills. Prepare 335ml per of 1L water
- ▶ 5,000ppm – NZ recommendation for cleaning of Blood Spills. Prepare 170ml per 1L of water
- ▶ 1,000ppm+ – recommendation for Environmental cleaning of surfaces contaminated with *C. difficile*

Prepare 35ml per 1L of water. Always disinfect after cleaning with a disinfectant registered for specific efficacy against *C.difficile*.

- ▶ 1,000ppm – recommendation for Environmental cleaning. Prepare 35ml per 1L of water

General Cleaning

For use as a cleaner, dilute 125mL into 5L of water (1:40) to remove germs from washroom surfaces and floors, and to remove stains in tea and coffee cups, etc. Rinse cups etc. with water.

*NHMRC, section B1.4.2 Routine environmental cleaning and HPS 2008, section 2.2.7 Environmental cleaning.

Technical Data

Description	
Appearance	Pale, yellow liquid
Odour	Chlorine
pH (concentrate)	12.9
Shelf life	1 year
Specific Gravity (20°C)	1.08

Available Items

Code	Description	Pack Size	Dilution	Availability
HH14333	Divercleanse	12x750ml	Hospital Grade Disinfectant Neat Infection Control cleaning See Directions for Use Manual cleaning 125ml to 5L water	AU & NZ
HH14336	Divercleanse	2x5L	As above	AU & NZ

These figures are typical values and should not be interpreted as specifications.

Safe handling and storage information:

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet. Store in original container. Store below 25°C. Not intended to be used on medical devices. Do not mix with detergents or other chemicals. Discard diluted solutions after use.

Product compatibility:

Under recommended conditions of use, Divercleanse is highly versatile and is suitable on most washroom surfaces such as shower recesses, tiles and toilets, as well as drains and waste pipes, refuse receptacles and bins. Divercleanse can also to remove stains from items such as tea and coffee urns and dish cloths. Divercleanse contains chlorine. Always spot test and ensure surface suitability before use. May discolour fabrics and surfaces. Do not use on enamel, laminates or porcelain if cracked or worn.

Safety Reminder:

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at www.diversey.com or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.

For additional information, please contact us at:

Diversey Australia Pty Ltd Toll free: 1800 647 779, BCPE Diamond (New Zealand) Ltd Toll free: 0800 803 615

www.diversey.com

© 2017 Diversey Inc. All Rights Reserved.