


How to use TASKI Jonmaster Mops


Golden Rules

1. Always replace the dirty mops with clean ones after each room.
2. Always start from the cleanest area before moving on to a more dirty area.
3. Remember - launder cloths and mops separately.
4. Never re-use the mops after they have been used in the washroom area.
5. Never use the mops on rough or concrete surfaces.


Method...




Attach the mop to the mop head by applying pressure downwards.




Adjust mop handle to comfortable height (chest level). Loosen handle by turning handle lock quarter of a turn to the left and pulling handle upwards. Lock handle in position by turning handle lock half a turn to the right.




Mop the floor with the leading edge of the mop starting at the furthest point from the exit, following a figure of 8 motion. For tough stains apply extra pressure to mop head using the ball of your foot.



When mop is soiled, remove from the mop head by stepping on the 2 edges of the mop. With both hands, pull the handle upwards to release the mop.



Place the mop head sideways across the mop and lift off the floor. Place in laundry bag. Place any unused mops into the laundry bag at the end of the shift for washing.



Replace the dirty mop with a clean one by repeating Step 1 above.



Use a fresh microfibre cloth dampened with disinfectant solution to clean the mop handle and frame after each isolation room and at the end of the shift.

